

HOW TO PROPERLY CLEAN YOUR KEYBOARD

DISCOVER THE HELPFUL TIPS FROM CHERRY

METHOD 1: SHAKE & TAP

- Turn the keyboard around, so the keys face down
- With this rotation, some crumbs and loose dirt will fall from the keyboard
- By slightly tapping and shaking, you can get rid of some larger dirt particles
- Cotton swabs and soft brushes are good tools against deep-sitting residue

METHOD 2: CLEANING SOLUTIONS

- Most CHERRY keyboards can be easily cleaned by gently wiping with soap and warm water
- Isopropyl and ethyl alcohol-based solutions can also be used
- Do not spray or pour the cleaning solution directly onto the device
- Wipe down the keyboard with a slightly damp cloth and mild cleaning agent
- Wipe down all the exterior surfaces

HELPFUL HINTS:

- Make sure your keyboard is switched off and completely disconnected from the PC before you begin cleaning
- ***Wireless keyboards with batteries should have the batteries removed***
- Refrain from using too much moisture on your keyboard
- Apply a mild cleaner to a soft, fiber-free cloth
- Make sure the keyboard is completely dry before using
- Refer to the user manual for complete instructions on how to properly clean your specific keyboard model
- If a deep clean isn't enough to bring your keyboard back to tip-top shape, visit cherryamericas.com to select a new keyboard for purchase

FOR MORE DETAILS

Please visit cherryamericas.com or contact a Cherry Americas Account Representative at sales@cherryamericas.com